

CARBONBOND CRACK REPAIR SYSTEM CB-0064

Carbonbond is a dry, unidirectional, noncorrosive carbon fiber fabric constructed with high strength carbon fibers. Carbonbond, in conjunction with Carbonbond saturates are used to repair cracks and reinforce the concrete or masonry structures. This kit is recommended to be used on dry cracks. If a wet crack is present, it is recommended to use this crack repair system in conjunction with the Hydro Sealant (HYP700E or HYP901E) to provide a water-tight barrier.

KIT CONTENTS

- Unidirectional Carbon Fiber (32 sheets, 12-inch-wide by 24-inch-long; covers 64-linear-feet by 1-foot-wide)
- 777 Epoxy Filler Part A Base (64 oz, 1:1 Mix)
- 777 Epoxy Filler Part B Hardener (64 oz, 1:1 Mix)
- 747 Epoxy Resin Part A Base (128 oz, 3:1 Mix)
- 747 Epoxy Resin Part B Hardener (43 oz, 1:3 Mix)
- Paint Stirrers (2)
- Roller Frame (1)
- Roller Covers (6)
- Gloves (4 pair)
- Poly Drop Cloths (2 - 4-feet. by 10-feet.)
- Measuring Bucket (1)
- Cardboard Squares (4)
- Plastic Putty Knife (1)



STORAGE

Keep Carbonbond resin components tightly sealed in their original containers until ready for use. Store at 60-80°F to facilitate handling and workability. Properly stored, Carbonbond resin has a shelf life of 12 months. All resins should be conditioned to 70-75°F prior to use for best viscosity, application and wet out capability. Fabrics should be kept boxed or bagged and away from direct sunlight, moisture or dirt/dust.

TYPICAL PROPERTIES

Reinforcement	Unidirectional Carbon Fiber Fabric
Color	Black
Dry Fiber Tensile Strength	720 ksi Certified
Dry Fiber Tensile Modulus	34 msi Certified
Laminate Tensile Strength	200 ksi
Laminate Tensile Modulus	13.7 msi
Laminate Thickness	0.02 inch



SURFACE PREPARATION

Concrete should be a minimum 50°F, adequately cured, possess adequate integrity and not be expelling excess water or hydration. A rule of thumb for cure of new concrete is 28 days cure at 70°F but that is not an assurance that the concrete has achieved adequate physical properties. The prepared area should extend 2-inches (on all sides) beyond the width of the carbon fabric. In general, the surface must be dry, clean, free from dust, paint, coating, oil or dirt and free from frost. For bumps, fins, and protrusions use hammer, sand blasting, pressure washing, shot blasting, grinding or other approved mechanical means to achieve an open-pore texture with a CSP (concrete surface profile) 3 or better per ICI Guideline 310.2R. Surface should be wiped with clean cloth after grinding, blasting, brushing surface to remove dust particles. Uneven surfaces (voids) and mortar joints must be filled with 777 Carbonbond Epoxy Adhesive/Filler Compound. (2 part 1:1 mix ratio).

RESIN MIXING

747 Carbonbond Resin is a two part epoxy system with a mix ratio of 3:1 (3 parts base epoxy, 1 part hardener). Epoxies generate heat during mixing and curing cycle, components must be mixed accurately and completely. Use a measured mixing container and roller pan with a high surface to volume ratio that will help minimize heat generation. Mix and keep resins from direct sunlight. Mix using a paint stirrer, avoid plunging it up and down in the bucket. This can fold air into the resin, which may cause bubbles to form in the coating after it has been applied. Be especially careful not to allow water to enter the mix. The working time for Carbonbond resin is 25-30 minutes at 70°F, mix only necessary amount to be applied within 30 minutes (15 oz. base part A and 5 oz. Hardener Part B for 8-ft of carbon fiber application). Working time will be longer at cooler temperatures and will be much shorter at higher temperatures.

APPLICATION

Apply one coat of mixed Carbonbond resin to saturate and cover concrete (approx. 20 mil thickness) with 1/4-inch nap roller. Make sure to cover complete application area (no dry concrete visible where carbon fiber will be applied, press roller firmly onto surface for good coverage). Place cut fabric piece against wall so fiber orientation is from top to bottom (vertical). Use hands to gently press fabric into resin for adhesion. Apply second coat of resin extending beyond dimensions of carbon fabric by 2-inches. Press firmly with roller keeping in same direction as fibers for maximum saturation and wet-out of fabric.

SAFETY AND FIRST AID

Avoid breathing vapors. Avoid contact with skin and eyes. Rubber gloves, mask, and goggles are recommended for safety. Review safety data sheets (SDS) prior to use.

CLEAN UP

Dispose of in accordance with local disposal regulations.

RECOMMENDED TOOLS

- Respirator (NIOSH/MSHA approved)
- Grinder with 5-inch diamond grinding wheel
- Power drill
- Goggles and face shield
- Disposable paint tray
- Scissors
- Tape measure



STEP BY STEP INSTRUCTIONS

1. Identify crack on wall. It is important to keep crack line as center point of repair area. Surface prep and fabric application will use approximately 7-inches on each side of the crack.
2. Using a grinder with 5-inch diamond wheel, grind area where the carbon fiber strips are to be placed (this will be 7-inches on each side of the crack). Remove any protrusions with a grinder or hammer. Brush area removing all debris, paint, coating, oil, and dirt. Make sure the wall is dry and wipe with clean, dry towel, if necessary.
3. Inspect wall and note any voids or bumps that would not provide a smooth/void free surface. Mix 5 oz. Epoxy Adhesive/Filler Compound, "Part A Epoxy" with 5 oz. "Part B Hardener".
4. As necessary, fill all cracks, joints and voids, where the wall strips will be placed, using the 777 Epoxy filler compound. Press firmly into cracks and voids to eliminate air pockets. Feather/trowel for smooth surface. A smooth surface is critical for proper adhesion. Voids or bumps will create voids which result in poor bonding of carbon fiber to structure.
5. Mix 15 oz. "747 Part A Epoxy" with 5 oz. "747 Part B Hardener" in a dry clean disposable bucket. Mix thoroughly. Pour resin/hardener mixture into a disposable paint roller tray.
6. With a 1/4-inch nap roller, start at the top of the wall and apply resin/hardener mixture to the area where the carbon fiber strip will be placed. Apply resin to area 2-inches wider on all sides than the fabric width (14-inch-wide total).
7. With the carbon fiber wall strips at a 90-degree angle across the crack, lay the wall strip from the bottom first (12-inch-wide by 24-inch-tall). Wearing rubber gloves on your hands, press the fabric into the resin saturated wall. Make sure the fabric is wrinkle free, all corners and edges are in resin and fabric is firm against the wall.
8. Rolling in the same direction as the carbon fiber, apply one more coat of the resin/hardener mixture with roller in the same direction as the fiber (this aids in fabric wet-out). Do not roll back and forth across the fiber direction. Make sure the carbon fiber wall strips are laying flat against the concrete. Use firm pressure to achieve good wet-out of carbon fabric.
9. Apply next carbon fiber strip above the first with 1/4-inch overlap. Make sure to use crack as center point for carbon fiber strip placement. Repeat steps 5 through 8 until the crack has been covered with the carbon fiber wall strips.
10. Clean-up and dispose of excess materials as stated in the SDS sheets.

It is the responsibility of each purchaser and end user of each Carbonbond product to determine the suitability of the product for its intended use. Prior to using any product, consult a qualified design professional for advice regarding the suitability and use and application of the product, including whether the capacity of any structural element may be impacted by a repair. "Dry Fiber Properties" are confirmed by certificate from the fiber manufacturer. "Laminate Properties" are to be used by technically skilled persons at their own discretion and risk. The properties do not constitute any warranty or guarantee. AJI values are for material selection purposes only. An externally applied CFRP system is a vapor barrier. Consult with a licensed, professional engineer to evaluate the results of encapsulating a porous substrate, and the installer must read, understand and follow all written instructions, and warnings contained on the product label(s), product data sheet(s), safety data sheet(s) prior to use. For use only by qualified applicators.

