

CARBONBOND BONDING EPOXY RESIN #500

DESCRIPTION

100% Solids moisture insensitive epoxy designed to bond carbon fiber fabric to concrete. Unique wetting properties allow for maximum penetration.

COMPLIANCES

ASTM C881
TYPE I, II, IV AND V
GRADES 1, 2, and 3
CLASS B & C

Supplier:

Intech Anchoring Systems
8250 Bunkum Rd.
Caseyville, IL 62232
Telephone: [618] 398-5503

PROPERTIES OF #500 BONDING EPOXY

Mix Ratio	2:1 by volume	
Pot Life	20 minutes	
Gel Time	ASTM C-881] @75°F
Initial Cure	ASTM C-881	
Final Cure	24-48 hours	

Mixed Viscosity 860 cps.

Cured Properties

Compressive Strength	ASTM D-695	11,100 psi
Compressive Modulus		289,000 psi
Flexural Strength		14,900 psi
Tensile Strength	ASTM D-638	9,100 psi
Elongation	ASTM D-638	4.7% min.

Benefits

- Easy 2:1 mix ratio
- No shrinkage
- Excellent adhesion to concrete
- Deep penetrating and tenacious bond

How to use

Surface Preparation: Structural repair via adhesion requires use of diamond-wheel grinder to open the pores of the concrete. Surface must be clean and sound. Remove all dirt, grease, wax, curing compounds and other foreign matter. Remove water and dust from all surfaces with an oil free air blast prior to application.

Mixing: Mix each component separately before blending two Parts A with one Part B by volume in a clean pail. Mix thoroughly for 3 minutes with a low speed drill.

Mix only the quantity that can be used within 20 minutes. If using automated or manual injection equipment, do not allow mixed material to reside in static mixing head for more than 10 minutes or blockage may result.

Application:

To gravity feed cracks on grade– sweep dry sugar sand into a V notched crack. Fill approx. 1/4". Pour neat #500 into crack until completely filled. Top off as necessary.

To gravity feed cracks above grade– seal underside of slab with epoxy surface sealer. When paste is set up, pour neat #500 into crack. Top off as necessary.

As carbon fiber bonding agent— using a small thin nap roller apply a coat of #500 approximately 1 inch wider than fabric, lay fabric up over crack with fabric tows at a 90 degree angle from crack. Using roller from the middle of the fabric roll out all air pockets. Apply a second coat of #500 over the entire fabric area. Allow to cure.

To anchor bolts, dowels and pins– Annular space around bolt should not exceed 1/8"; depth of embedment is typically 10-15 times the bolt diameter.

Limitations/Precautions

- Temperature of substrate must be above 40°F.
- New Concrete must be at least 28 days old.
- Do not thin, solvents prevent proper cure.
- Do not seal exterior slabs on grade

Component A Irritant– prolonged contact with skin may cause irritation. Avoid eye contact.

Component B Corrosive– Contact with skin may cause severe burns. Avoid eye contact. Product is a skin sensitizer. Use safety glasses and gloves. Avoid breathing vapors. Use adequate ventilation. In case of skin contact, remove any contaminated clothing. Wash area of contact with soap and water. For eye contact, flush immediately with plenty of water for at least 15 minutes. Contact physician immediately.

Packaging

- 30 oz. dual unit
- 1.5 gal. dual unit

Storage


#500 should be stored in a dry environment between 60-80°F. Unmixed material may crystallize if exposed to temperatures below 60°F.

Technical Service

Complete technical service and specification services are available from the manufacturer and their authorized representatives.

Warranty

Intech Anchoring Systems does not provide any warranty either written or implied with this product.



CONCRETE REPAIR
SOLUTIONS
FROM INTECH

137CB-CarbonbondBondingEpoxyResin#500

is distributed by

INTECH ANCHORING SYSTEMS

intechanchoring.com

st. louis 8250 Bunkum Rd

Caseyville, IL 62232

michigan 35850 Industrial Rd

Livonia, MI 48150

o 800.223.7015

f 618.398.5722 | f 734.432.5119

INTECH[®]
ANCHORING
SYSTEMS